



Schneller Manufacturing Inc.

8052 118th Ave. N. Largo, Fl. 33773

Phone (727)549-2100 Fax (727)549-2152

Handle Quick Release Assembly Instructions

Carefully unpack the Handle Quick Release components. You should have received 2 main bodies, 2 adjustable handles, 2 Allen Head Bolts, 2 Aluminum Spacers and 2 Nylocks.

First remove the existing parts from your stool. You should have removed the 2 wing nuts, the 2 carriage bolts and the 4 curved washers. All that should be remaining are the holes in the tubing. You will also have to remove the two black caps that are on the end of the long handle tubes.

Put one of the Allen Head Bolts thru the hole in the main body. The grooved side of the main body should be facing up. Now push the bolt with the main body attached thru one of the holes in the tubing. The groove should mate up with the tubing on the Stool leg. Attach the quick Release Main Body so it hangs below the Stool tubing.

Install one of the Aluminum spacers on the bolt, and install a Nylock. Tighten the Quick Release Main Body onto the Stool using a 3/16" Allen Wrench (not included) thru the bottom and a 7/16" wrench (not included) on the top. Repeat this procedure on the remaining side, and the job is complete.

The adjustable handles can be placed in any location by simply pulling the handle straight out and moving the handle to the desired position. If the top handle does not fit into the holes on the Quick Release, loosen the bolts on the main body, and insert the top handle. Now retighten the main body bolts.

There are pictures on our web site at www.schnellermanufacturing.com showing the proper installation procedure.

Thank you for purchasing our products. I hope this accessory makes your shooting experience a little more enjoyable.

Bob Schneller



Schneller Manufacturing Inc.

8052 118th Ave. N. Largo, Fl. 33773

Phone (727)549-2100 Fax (727)549-2152