



Schneller Manufacturing Inc.

8052 118th Ave. N. Largo, Fl. 33773

Phone (727)549-2100 Fax (727)549-2152

Stool Lock Instructions

You will need two 7/16 Wrenches to install the Stool Lock. First you must decide which side of the stool you want to put it on. If you are using the Vertical Rifle Holder accessory I would suggest you use the other side. The Stool Lock will get in the way of the Rifle in the vertical position. It will not get in the way of the Vertical Scope Holder if you are using that.

Once you have decided which side to put it on, you will need to remove the bolt that is located at the X joint that the stool hinges on when it is folded up. Remove the bolt on the side you want to put the Stool Lock on. Save the Flat washers and the lock nut. Replace the long 1/4" bolt with the new bolt supplied with the Stool Lock. Insert the bolt from the inside to the outside. Remember to place a flat washer on the bolt first, then a flat washer between the tubes, and another flat washer on the outside. Install the lock nut and retighten with a 7/16" wrench. Do not over tighten this nut or the stool will not fold up. It does not have to be tight; the lock nut will prevent it from coming off.

Now install the Stool Lock on the remaining part of the 1/4", with the "U" facing in and the legs on the top and bottom of the X joint formed by the two stool halves. Install the wing nut and hand tighten it. That's all there is to it.

When you get to the range in the morning, simply install the Stool Lock and the stool can no longer fold up. At the end of the day, remove it and the stool will fold up as normal.

I hope this accessory will make your shooting a little more enjoyable. Thanks for purchasing our products.

Bob Schneller